




HEAVY-DUTY FLAME PROTECTOR PAD



- * NEVER SOLDER WITHOUT FLAME PROTECTION
- * ALWAYS PROTECT FLOORS, STUDS, WALLS, AND OTHER SURFACES FROM FLAMES AND SPARKS
- * ASBESTOS FREE
- * USE WITH HIGH TEMPERATURE TORCHES
- * DURABLE, FLEXIBLE AND REUSABLE
- * SAFER AND MORE EFFECTIVE THAN FIBERGLASS AND OTHER WOVEN HEAT SHIELDS

PROTECTS IN EXCESS OF 1300°C (2,500°F)

NO SMOKE*NO ASBESTOS*NO BREAKDOWN*USE WET OR DRY

DESIGNED FOR USE WITH HIGHER TEMPERATURE ACETYLENE, MAPP AND PROPANE TORCHES.
USE WET OR DRY WHERE HIGHER TEMPERATURE PROTECTION IS REQUIRED.

INSTRUCTIONS:

USE IN A WELL VENTILATED AREA. DESIGNED FOR USE WITH HIGHER TEMPERATURE ACETYLENE, MAPP AND PROPANE TORCHES. USE WET OR DRY WHERE HIGHER TEMPERATURE PROTECTION IS REQUIRED. IF WORKING IN TIGHT AREAS, FABRIC MAY BE FOLDED OVER.

HANDLING AND STORAGE:

GRAPHITE FIBERS ARE ELECTRICALLY CONDUCTIVE AND MAY CAUSE SHORT CIRCUITS WHICH MAY RESULT IN DAMAGE TO, OR MALFUNCTION OF ELECTRICAL EQUIPMENT. ALL FORMS OF ELECTRICAL EQUIPMENT, ENCLOSURES AND CIRCUITS IN OR NEAR AREAS WHERE FIBRES ARE USED SHOULD BE PROPERLY PROTECTED AGAINST INFILTRATION OF OR CONTACT WITH AIRBORNE PARTICLES OR FIBRES.

OTHER PRECAUTIONS:

WASH WORK CLOTHES SEPERATELY FROM OTHER CLOTHES.

G. F. THOMPSON CO. LTD.

NEWMARKET, ONTARIO, CANADA

www.gfthompson.com